

## Getting started

### Contacts

Displays a list of your contacts.

### Call History

Displays a list of missed, outgoing and received calls.

### Voicemail

Provides access to your voicemail service.

### Settings

Provides services and options that allow you to customize your phone.

### Volume

Adjusts the volume for the ringer, handset, speaker and headset.

### LCD Touchscreen

UI navigation is performed using the LCD touchscreen. On the Home screen, swipe left and right on the programmable key area to access additional key pages. In the application and settings menu, swipe up and down to scroll through lists. To select an item, tap the respective item on screen.

### Programmable Keys

Up to 96 programmable keys, a maximum of 16 programmable keys per page.

### Softkeys

Five state-sensitive softkeys.

### Goodbye

Ends active calls and used for exiting menus.

### Redial

Displays Call History with a list of outgoing calls.

### Hold

Places an active call on hold or resumes a call from hold.

### Mute

Mutes/unmutes all outgoing audio from headset, handset or speaker.

### Speaker/Headset

Toggles the phone's audio between speaker and headset.

## Activating your phone

Follow the **Installation Guide for the Mitel 6940 IP Phone** to connect the phone to your network.

After the phone boots, press the **ACTIVATE** soft key.

Enter your numeric OfficeSuite UC extension, and then enter your numeric PIN.

Press **ENTER** or the **#** key and your phone will login and be ready for use.

To program speed dial and feature keys, login to the MyOfficeSuite portal at [myofficesuite.broadviewnet.com](http://myofficesuite.broadviewnet.com).

## Basic call handling

### Making a call

1. Lift the handset or press the  key, and dial the number.
2. Press the **Line** programmable key and dial the number.

### Ending a call


Place the handset back in its cradle, press the **End Call** softkey, or press the  key.

### Answering a call



Lift the handset or press the  key for hands-free operation.

### Redialing




Press the **Redial** softkey once or the  key twice to call the last dialed number as displayed on the Home screen – or –

Press the  key once to access the Call History application with a list of recently dialed numbers. Swipe up and down to scroll through the entries, select the entry, and tap the **Dial** softkey to redial the selected number.

### Muting

Press the  key while on an active call to mute the microphone for your handset, headset, or speaker. Press the  key again to unmute the audio.

### Holding and resuming

1. To place an active call on hold, press the  key. A  (hold) icon flashes on the respective **Line** key.
2. To resume the call, press the  key again or press the respective **Line** key.